



FUNCTION KEYS ON CELLULAR DEVICE


FIG. 1



DESIGNATION MENU

- | | |
|----------------|---------------|
| 1. CAMERA #1 | 10. SPEAKER A |
| 2. CAMERA #2 | 11. SPEAKER B |
| 3. CAMERA #3 | 12. SPEAKER C |
| 4. CAMERA #4 | 13. SPEAKER D |
| 5. CAMERA #5 | 14. SPEAKER E |
| 6. CAMERA #6 | 15. SPEAKER F |
| 7. CAMERA #7 | 16. SPEAKER G |
| 8. CAMERA #8 | 17. SPEAKER H |
| 9. CAMERA #8 | 18. SPEAKER I |
| 10. CAMERA #10 | 19. SPEAKER J |

___ living room	___ dining room	___ kitchen
___ 1 st bedroom	___ 2 nd bedroom	___ 3 rd bedroom
___ 4 th bedroom	___ other #1	___ other #2
___ other #3		




A.
Raised Window Activates Home Computer's
Security System


FIG. 2

Real-time Connectivity Activates Simultaneously
With Security System

B.



D.
Image To Cell Phone Monitor



C.
Real-time Connection Feeds Intruders

E. Cell Phone Activated



FIG. 3

BEST AVAILABLE COPY




FIG. 4

BEST AVAILABLE COPY

1a

Two Surprised Burglars On
Real-time Cell Phone Monitor.



2a
Designated Keys Assigned as Function Keys
To Control Home Cameras & Speakers

FIG. 5

BEST AVAILABLE COPY